



Front All Season Mats

OWNER'S MANUAL

Introduction

Thank you for purchasing this Honda accessory. Please read this Owner's Manual carefully before using this accessory, and keep this manual in the glove box for future reference.

- This product is designed to be used exclusively on Honda cars. Honda is not responsible if the unit is used for any other intended purpose.
- The Owner's Manual should be considered a permanent part of your vehicle. It should remain with the vehicle at all times and stay with the vehicle if it is sold.

SPECIAL MESSAGES

We provide many important safety messages in this manual. For your safety and safety of others, pay special attention to all warnings preceded by this alert symbol .

Failure to follow the warnings contained in this manual can result in serious injury or accident.

DANGER

Indicates that severe personal injury or death will result if instructions are not followed.

WARNING

Indicates a strong possibility that serious injury or death may result if instructions are not followed.

CAUTION

Indicates a possibility that minor personal injury may result if instructions are not followed.

OTHER SYMBOLS

- If instructions are preceded by the following symbols, they will give helpful advice or information.

NOTICE

- Gives advice to prevent damage to the product.
- Gives advice to handle emergency situation.

NOTE


Gives helpful information or instructions to be followed in using the product.

Installing the Front All Season Mats (with floor carpet mats)

- 1 Slide the driver's seat backward.
- 2 Remove the front floor carpet mat.
- 3 Remove the covers.

NOTICE


- Be careful not to damage the cover.
- Keep the cover carefully.



A	FRONT FLOOR CARPET MAT
B	FLAT-TIP SCREWDRIVER
C	CUTOUT(2)
D	COVER
A	COVER (Keep.)(2)
B	Alternate work on both sides.
C	FRONT FLOOR CARPET MAT (Fold.)


4 Reinstall the front floor carpet mat.

5 Make sure that the knob is unlocked.




A	FRONT FLOOR CARPET MAT
B	DRIVER'S SEAT
A	KNOB (unlock)

6 Install the attachment.



A	FRONT FLOOR CARPET MAT
B	ATTACHMENT(2)
C	HOLE
D	CUTOUT
A	Push.
B	Turn 90°.
C	Lock: Align the triangle marks.


7 Install the front all season mat.



A	ATTACHMENT(2)
B	RETAINING TAB(2)
C	DRIVER'S SEAT
D	FRONT ALL SEASON MAT
A	Push.
B	KNOB (Turn.)
C	Lock: Align the triangle marks.
D	((Handling instructions)) Fix the mat with included holder attached to the vehicle or the attachment attached to FLOOR MAT.
E	((How to remove the attachment)) Lift the two tabs and turn 90 degrees.

Removing the Front All Season Mats (with floor carpet mats)

- 1 Slide the driver's seat backward.
- 2 Remove the front all season mat.




A	KNOB (Turn.)
B	UNLOCK
C	DRIVER'S SEAT (Slide backward.)
D	FRONT ALL SEASON MAT (Keep.)

3 Remove the attachment.

NOTICE

- Keep the attachment carefully.




A	DRIVER'S SEAT
B	FLOOR CARPET MAT
A	RETAINING TAB (Lift up.)(2)
B	Turn 90°.
C	ATTACHMENT (Keep.)(2)

4 Install the covers.

NOTICE

- Make sure that the floor carpet mat is not pinched.




A	COVER(2)
B	GROMMET(2)
C	DRIVER'S SEAT
D	FLOOR CARPET MAT
A	Align the cutout in the cover with the cutout in the grommet.

5 Install the floor carpet mat.

NOTICE

- Make sure that the floor mats are secured.



A	RETAINING TAB(2)
B	DRIVER'S SEAT
C	FLOOR CARPET MAT
A	Push.
B	KNOB (Turn.)
C	Lock: Align the triangle marks.

